## Kongsberg X Starter

The Kongsberg X Starter is a cutting table that offers value, reliability, precision and ease of use at an attractive investment level.

With Kongsberg X Starter you have a safe entry to digital finishing with the flexibility to upgrade to more speed or versatility whenever you like to. Kongsberg X Starter is the Kongsberg experience for less.

## Technical Specification

	X20	X24			X20 X24	
Work area, all tools	1680 x 1270 66 x 50	1680 x 3200 66 x 126	mm in.	Repeatability	± 50 ± .0019	μm in.
Max. material size	1740 x 1750 68 x 69	1740 x 3575 68 x 140	mm in.	Max. speed	30 20	m/min IPS
Overall dimensions	2780 x 2450 109½ x 96½	2780 x 4050 109½ x 159½	mm in.	Max. acceleration <sup>2</sup>	3 0.3	m/s² G
Weight	455 / 1000	630 / 1390	kg / lbs	Vertical tool force	220	Ν
Position accuracy <sup>1</sup>	± 200 / ± .0078		µm / in.	Vacuum sections	1	
Repeatability	± 50 / ± .0019		µm / in.	Traverse clearance <sup>3</sup>	50 / 2"	mm / in.

1 Applies across total work area.

2 May be reduced with certain tool- and configuration combinations.

3 Measured without cutting underlay. Maximum cutting thickness is tool dependent.



## X Starter Bundles

SC

BUNDLE	DESIGN STARTER	SIGN STARTER	SIGN LIGHT STARTER	FLEXO STARTER
Description	Packaging and display sample making	Entry level sign ap- plications	Entry level sign appli- cations (no milling)	Flexo plate cutting
Model	X20 and X24	X20 and X24	X20 and X24	X20
ToolHead	FlexiHead	MultiCUT	FlexiHead	FlexiHead
Milling Spindle	-	1kW	-	-
iPC lisence	iPC Basic	iPC Sign Standard	iPC Sign Standard	iPC Flexo
Camera/ vision cut- ting	-	i-camera	i-camera	i-camera
РС	Included	Included	Included	Included
Front cover/ integra- ted operator panel	Included	Included	Included	Included
Vacuum pump	6kW	6kW	6kW	6kW

## X Starter Upgrades

SPEED UPGRADE	THE SPEED UPGRADE OPTION INCLUDES			
Speed	X Starter: 30 m/min - 20IPS	X: 50m/min - 33IPS		
Acceleration	X Starter: 3 m/s2 - 0.3G	X: 5.6 m/s2 - 0.56G		

VERSATILITY UPGRADE	THE VERSATILITY UPGRADE OPTION INCLUDES
Design Starter	Upgrade to two (X20) or four (X24) vacuum zones
Sign Starter, Sign Light Starter	<ul> <li>Upgrade to two (X20) or four (X24) vacuum zones</li> <li>Workstation upgrade</li> <li>Upgrade from iPC Sign Standard to Sign Production</li> <li>Ability to add conveyor feed option, enabling automated sheet- or roll feeding</li> </ul>
Flexo Starter	<ul><li>Upgrade to two vacuum zones</li><li>Workstation upgrade</li></ul>
All Starter bundles	<ul> <li>Allowing extended traverse clearance for materials up to 86 mm</li> <li>Allowing adding other toolheads like PowerHead and FoamHead Allowing iPC license upgrades</li> </ul>

